



SPARE PARTS AMBASSADEUR 8500

4554	Right inner plate	8868	Crank ferrule
4555	Right side plate	8902	Left side plate screw
4557	Left side plate	8903	Retaining spring
4564	Main gear bushing	8905	Reel seat screw
4565	Drag washer	8907	Pillar and bracket screw
4566	Cog wheel	* 8913	Screw
4567	Drag washer	8948	Ratchet
4568	Click wheel	9696	Star wheel
4569	Drag washer	9709	Bearing
4570	Washer for click	9710	Clutch release arm
4571	Drag washer	9713	Free spool pressarm
4574	Cog wheel	9714	Connecting arm
4575	Spool	9715	Clutch arm spring
4577	Bushing for spool	9716	Press arm spring
4578	Bushing spacer	9717	Base washer
4579	Handle	9733	Spacing washer
4581	Locking washer	9735	Convex spacer
4582	Brake wheel	9736	Bushing spacer
4583	Spacing washer	9741	Retaining spring
5229	O-ring	9750	Felt packing
6968	Handle nut	9751	Concave washer
8808	Left inner plate	* 9764	Spool centering washer
8816	Bearing retainer ring	* 9766	Bearing cushion
8825	Reel foot	* 9767	Centrifugal brake bearing
8828	Pillar	* 9768	Spool adjusting cap, left
8845	Clutch spring lock	9774	Spool cap, left, complete
		9781	Washer

* Discontinued

Please specify reel model number and number in reel foot (6 figures) when ordering parts.

NOTE: Vide page 1:57!