



**57**  
 80 01 04

## SPARE PARTS CARDINAL 57

- |   |   |
|---|---|
| <ul style="list-style-type: none"> <li>190 Screw</li> <li>* 216 Screw</li> <li>* 3934 Ball bearing retaining ring</li> <li>6720 Locking washer</li> <li>8595 Line roller and bushing</li> <li>8597 Bushing</li> <li>8711 Nut</li> <li>8714 Protecting washer</li> <li>9885 Bail spring</li> <li>9886 Bail spring</li> <li>10711 Screw</li> <li>* 10712 Spring</li> <li>* 10713 Anti reverse ratchet</li> <li>10714 Plate spring</li> <li>10715 Anti reverse button</li> <li>10717 Bail attachment</li> <li>10724 Brake nut plate</li> <li>10725 Rubber washer</li> <li>10726 Fork spring</li> <li>10729 Friction washer</li> <li>10730 Click wheel</li> <li>10731 Driving washer</li> <li>10732 Friction washer</li> <li>10746 Line pick-up ejector</li> <li>10747 Stop ring</li> <li>10754 Spring washer</li> <li>10769 Brake knob</li> <li>10777 Screw</li> <li>10778 Ball bearing</li> <li>10782 Screw</li> <li>10789 Washer</li> <li>11173 Nut</li> <li>* 11247 Locking washer</li> <li>* 11303 Housing</li> <li>11306 Housing plate</li> </ul> | <ul style="list-style-type: none"> <li>* 11309 Winding cup</li> <li>* 11313 Worm main gear with slot</li> <li>11313 Worm main gear, hexagonal</li> <li>* 11317 Worm main gear shaft</li> <li>11318 Line distributor wheel</li> <li>11321 Screw</li> <li>11323 Connecting link</li> <li>11325 Bail arm</li> <li>11326 Cover plate</li> <li>11327 Bail stopper</li> <li>11330 Spool</li> <li>* 11331 Main shaft</li> <li>11336 Bail</li> <li>11338 Anti reverse arm</li> <li>* 11342 Handle with thread stud</li> <li>11342 Handle, hexagonal</li> <li>* 11344 Handle locking screw, Ø 4 mm</li> <li>11344 Handle locking screw, Ø 5 mm</li> <li>* 11345 Driving stud</li> <li>11357 O-ring</li> <li>11359 Arbor</li> <li>11369 Housing</li> <li>11377 Anti reverse ratchet</li> <li>11378 Stop spring</li> <li>11383 Driving fork</li> <li>11384 Screw</li> <li>11397 Locking washer</li> <li>11558 Ball bearing retaining ring</li> <li>11721 Driving stud</li> <li>11725 Main shaft</li> <li>11738 Locking pin</li> <li>12393 Bushing</li> <li>12398 Worm main gear shaft</li> <li>12586 Winding cup</li> <li>12714 Spring washer</li> </ul> |
|---|---|

\*/old model